



Installation Manual >> Crash Bars >> Husqvarna 701 Enduro

See attached pages for product kit,
recommended tools.



1.

Installation Manual >> Crash Bars >> Husqvarna 701 Enduro

1. Remove the top factory M8 Allen bolt on the left side of the motorcycle.

2. Remove the lower factory Allen bolt on the left side of the motorcycle.



2.

OUTBACK MOTORCYCLE

3. Install the left side crash bar.



4. Insert the supplied M10x30mm bolt on the top. Only one or two turns to keep the bolt loose.



3.

OUTBACK MOTORCYCLE

5. Insert the supplied M10x30mm bolt below. Only one or two turns to keep the bolt loose.



6. Remove the lower factory Allen bolt on the right side of the motorcycle.



4.

Installation Manual >> Crash Bars >> Husqvarna 701 Enduro

7. Remove the upper factory Allen bolt on the right side of the motorcycle.



8. Mount the right side crash bar.



5.

Installation Manual >> Crash Bars >> Husqvarna 701 Enduro

9. Insert the supplied M8x30mm Allen bolts and only thread in both one or two turns to keep them loose for easier fitment.



10. Mount the cross brace as shown in the photo.



6.

OUTBACK MOTORTEK

11. Insert and supplied M6x20mm hex bolts on both sides.



12. Then hand-thread the supplied locking nuts. Use 2x 10mm spanners/wrenches to tighten.



7.

OUTBACK MOTORTEK

13. Finally, go ahead and tighten all the bolts and nuts to torque specs and make sure to check again after going out for a test ride.



Should you have any question regarding the installation, please contact us at info@outbackmotortek.com

or call toll free at 1 877 931 3636

Important note! Outback Motortek recommends its customer to install their products by a certified, experienced motorcycle mechanic. Outback Motortek assumes no liability for any accident, injury, death, loss, or other claim related to or resulting from the use of its products. In no event shall Outback Motortek be liable for incidental or consequential damages relating to or resulting from the use of its product or any of its parts.

8.